

# LawnBott® Greasing & Proper Assembly

Use Lucas Oil Red Grease with Anti-Sieze (or equivalent) available at Auto Parts Stores

Use Thread Lock on All Important Screws



## Rear Wheel Hubs

Remove old grease if it is dirty or is a different type. Apply new grease as shown.

**Purpose:** Prevention of heat caused by friction.



## Rear Wheel Hex Nut

Apply a thin layer of grease on each hex nut face. Install wheel, then remove excess grease before installing wheel bolt.

**Purpose:** prevent rear wheel from seizing onto the hex nut.



## Apply Thread Lock

Apply a thread lock fastener adhesive, such as Lock-Tite brand to all important screws:

- The screws that hold the motor to the frame
- The large bolt that holds the wheel onto the motor shaft.
- Blade motor mounting screws, if motor is removed for service



## Front Wheel Spindles

This step applies to models that have front wheels, such as Evolution, Deluxe, Professional, LB32XX, LB2XXX, LB35XX, LB200EL & LB300EL.



Contact us for Our Winterization Pricing